

Instant Alert Monitor

FOR FLOOR HEATING SYSTEMS

FEATURES:

- Alerts when heating cable is cut or damaged during installation.
- Battery operated.
- Attach up to three separate heating cables or mats.
- Green light indicates that the Alert Monitor is operating.
- Red light indicates that lead wires have come loose from terminals or damaged (opened or shorted cable) has occurred during installation.
- Alarm sounds when red light turns on.
- Provides peace of mind knowing installation was done correctly the first time.



MODEL	UPC# 093319 PART #	DESCRIPTION
FCS11	40088	Instant Alert Monitor

The FCS11 Instant Alert Monitor is designed to alert the installer if continuity in the heating wire is broken by cutting the wire or if there is a short circuit between the ground and heating wires. Connect the Instant Alert Monitor to your floor heating cable or mat system BEFORE starting installation and leave it connected until the job is complete.

INSTALLATION




Figure 1

1 cable or mat installation




Figure 2

2 cable or mat installation




Figure 3

3 cable or mat installation



Quick and easy installation provides peace of mind while installing heating floor cable or mats.